

Incidence Perfect NG

User Manual (Beta)



Firmware: 2026.2.9

Build date: 2026-02-26

Revision: 0bd6830

Table of Contents

- 1) Getting Started
- 2) Touch Controls (Everyday Use)
- 3) BOOT Button (Physical Control)
- 4) MODE (Orientation Change, Guided)
- 5) ALIGN (Mechanical Alignment, 6 Steps)
- 6) Serial Control (Optional)
- 7) Troubleshooting
- 8) Beta Tester Checklist + Feedback
- Appendix A: Hardware Notes
- Authorship
- License And Warranty

Incidence Perfect NG is a compact 2-axis inclinometer/incidence meter built around an ESP32-S3 + AMOLED touchscreen. It measures **roll** and **pitch** and provides guided workflows for **ZERO**, **MODE**, **ROTATE**, and **ALIGN**.

Beta note: This manual describes the current firmware behavior. If something differs on your device, report the **firmware version shown on the splash screen**.

1) Getting Started

Power + Boot

- Connect the device over USB power.
- On boot you'll see the splash screen with the firmware version in the lower-right.
- After boot, the live readout screen appears (roll/pitch).

What You're Looking At

- **Top status line** shows:
 - orientation mode (SCREEN UP OR SCREEN VERTICAL)
 - axis view (BOTH, ROLL, PITCH)
 - rotation (ROT 0 OR ROT 180)
 - live state (LIVE OR FROZEN)
 - **Readouts:**
 - ROLL (left) and PITCH (right) in degrees
 - colors shift for large angles (warning, then critical)
 - **Bottom buttons:**
 - ZERO, AXIS, MODE, ALIGN, ROTATE
-

2) Touch Controls (Everyday Use)

ZERO

Use when the tool is resting in the reference position.

- Tap ZERO.
- A brief confirmation message appears.
- Values settle around 0.00.

AXIS

Choose what you want to focus on:

- Tap **AXIS** to cycle: BOTH -> ROLL -> PITCH -> BOTH.

ROTATE (180 degrees)

Use when the device is physically hard to read and you want to flip the UI.

- Tap **ROTATE** to toggle ROT 0 / ROT 180.
- Rotation persists after reboot.

Freeze / Unfreeze

Use freeze when you want to capture a reading without chasing tiny motion.

- Tap the **readout area** (the roll/pitch values) to toggle LIVE / FROZEN.
 - When frozen, the displayed values hold steady.
-

3) BOOT Button (Physical Control)

The board has a physical **BOOT** button (GPIO0, active-low). It mirrors key actions so you can operate the device when the screen is hard to reach.

In normal measurement mode:

- **Short press**: toggle freeze (LIVE <-> FROZEN)
- **Long press (~1.2s)**: cycle **AXIS** (BOTH -> ROLL -> PITCH)
- **Very long press (~2.2s)**: enter/toggle **MODE** workflow (orientation change)

While holding **BOOT**, an on-screen hint shows what will happen on release and a progress indicator for the next threshold.

4) MODE (Orientation Change, Guided)

MODE changes how the device interprets orientation.

- **SCREEN UP**: standard "screen facing up" use case
- **SCREEN VERTICAL**: use case where the tool is used on a vertical surface

Touch Workflow

1. Tap `MODE` once to enter the guided workflow.
2. The UI shows which orientation to position the device into (target).
3. Tap `CONFIRM`, then **hold the device still**.
4. A countdown appears; when it reaches zero, the new mode auto-applies.
5. Tap `CANCEL` at any time to abort without changes.

BOOT in MODE Workflow

- Short press: `CONFIRM`
 - Long press: `CANCEL`
-

5) ALIGN (Mechanical Alignment, 6 Steps)

Use `ALIGN` after mounting/enclosing the device to remove systematic bias.

This is a guided, 6-orientation capture procedure. The device will prompt you through the positions and ask you to capture each one.

Touch Workflow

1. Tap `ALIGN`.
2. Follow the on-screen instruction (example: `Place tool: SCREEN UP`).
3. Tap `CAPTURE` to record that step.
4. Repeat until all steps are captured.
5. Tap `CANCEL` to abort safely at any time.

BOOT in ALIGN Workflow

If the screen is hard to access (for example screen-down steps):

- `BOOT` short press = `CAPTURE`
-

6) Serial Control (Optional)

If connected to a PC, you can control the same workflows via serial (115200).

Core commands:

- `z`: `ZERO` now

- a: AXIS cycle (BOTH -> ROLL -> PITCH)
- r: ROTATE 180 toggle
- c: start ALIGN workflow
- c: confirm/capture (context-sensitive)
- m: start MODE workflow to the opposite orientation
- u: start MODE workflow targeting SCREEN UP
- v: start MODE workflow targeting SCREEN VERTICAL
- x: cancel pending MODE workflow

Serial and touch workflows are designed to stay synchronized.

7) Troubleshooting

Touch Feels Hard To Trigger

- Use BOOT alternatives for critical actions.
- Try deliberate taps (not swipes) centered on the button.

Serial Monitor Doesn't Resume After Reset

- Some setups require closing/reopening the serial monitor after reset.
- Always report the firmware version shown on splash if you see inconsistent serial behavior.

MODE Doesn't Apply

- Ensure you press CONFIRM, then keep the device still until the countdown finishes.
 - If you move, the countdown may reset (by design).
-

8) Beta Tester Checklist + Feedback

If you're testing externally, use:

- ../release/beta-checklist.md
- ../release/tester-handoff-note.md

When reporting an issue, include:

1. Firmware version (from splash)
2. Exact steps to reproduce
3. Expected vs actual result

4. Photos/video if UI-related

Appendix A: Hardware Notes

For reference bring-up settings (Arduino IDE), see:

- `../hardware/board-settings.md`
 - `../hardware/board-settings-arduino-ide.jpg`
-

Authorship

This firmware and UI were developed by **Per Takman**, with assistance from **OpenAI Codex (Codex CLI)**.

License And Warranty

- The project source code is released under the MIT License.
- The software is provided "AS IS", without warranty of any kind.
- Third-party manuals, schematics, and library dependencies remain under their respective original licenses/terms.